## **B**i200 Firmware Update Instructions:

- 1. Download the appropriate .bin file and save it to a local computer. (you may have been emailed the latest BIN file from one of our support staff.)
- 2. (WITH POWER CORD UNPLUGGED) Attach an Ethernet cable to the Ethernet port on the back of the Bi200. Then plug in power cord and wait for the RED LED above the power button to turn on the unit. Turn it on.
- 3. Open any browser on your computer (preferably chrome) and type in <a href="www.mybryston.com">www.mybryston.com</a> in the URL window.
- 4. You should see a device listed as Bi200 (with your serial #) click on that box.



5. You will now see the Virtual Remote of the Bi200. In the bottom left corner - Click Firmware Update (Click it Twice)



6. On the next screen you want to choose the BIN file you just saved to your computer.

Firmware Update Upload
This page sends the chosen file in 2Kb chunks using the /upload endpoint. The uploaded file is stored in the /update directory.

The update will then start automatically - just wait for it to finish and system will reboot. Once it reboots push power button to shut down. Then please unplug the power cord to the unit for 10 seconds to cut all power. Plug back in and DONE!